

Dominator instrukcija

Main Menu Options

- d001** 1. DMX Channels
- Aut0** 2. Automatic Programs
- Sou0** 3. Sound-active Programs
- SLA** 4. Slave

⚠ You can only change a certain setting when the display is blinking. **⚠**
 If you can't change a certain value, please press the **MODE**-button once and then change the value.

1. DMX Mode

With this menu you can set the DMX address.

- 1) Press the **FUNC** button, until the display shows **d001**.
- 2) You can choose 506 different DMX addresses.
Use the Up / Down buttons to select the required address from **d001 - d506**.
- 3) Use the **ENTER** button to store your setting.

2. Automatic Programs

- 1) Press the **MODE** button, until the display shows **Aut0**.
- 2) Use the Up / Down buttons to scroll through the entire menu.

- Aut0** Laser + RGBWA + 8x White LEDs
- Aut1** Laser + RGBWA
- Aut2** Laser + 8x White LEDs
- Aut3** RGBWA + 8x White LEDs
- Aut4** RGBWA
- Aut5** Laser
- Aut6** 8x White LEDs

- 3) When you press the **ENTER** button in Auto Mode, you can set the speed of each automatic program.
The speed can be set between **50 - 5100**. This is from slow to fast.
- 4) Use the **ENTER** button to store your setting.

3. Sound-activated Programs

- 1) Press the **MODE** button, until the display shows **Sou0**.
- 2) Use the Up / Down buttons to scroll through the entire menu.

- Sou0** Laser + RGBWA + 8x White LEDs
- Sou1** Laser + RGBWA
- Sou2** Laser + 8x White LEDs
- Sou3** RGBWA + 8x White LEDs
- Sou4** RGBWA
- Sou5** Laser
- Sou6** 8x White LEDs

- 3) The device is music-controlled by its built-in microphone. The audio sensitivity control (6) allows you to adjust the sensitivity of the device. A clockwise movement increases the sensitivity.
- 4) Use the **ENTER** button to store your setting.

4. Slave Mode

With this menu you are able to set the device as a slave device.

- 1) Press the **MODE** button, until the display shows **SLA**.
- 2) You can use the same functions on the master device. This means on the master device you can set your desired operation Mode and all slave devices will react the same as the master device.
- 3) Use the **ENTER** button to store your setting.

Menu Overview

