

**DMX-protocol**

Channel Mode			Value		Feature
5 CH	6 CH	7 CH			
1	1	3	<b>Red</b>		
			0	255	Red 0 - 100 % increasing
2	2	4	<b>Green</b>		
			0	255	Green 0 - 100 % increasing
3	3	5	<b>Blue</b>		
			0	255	Blue 0 - 100 % increasing
4	4	6	<b>White</b>		
			0	255	White 0 - 100 % increasing
5	5	1	<b>Dimmer intensity</b>		
			0	255	Gradual adjustment of the dimmer intensity from 0 to 100 %
	6		<b>Strobe</b>		
			0	0	No function
			1	5	Sound Control (15 colors)
			6	10	No function
			11	255	Strobe-effect with increasing speed
		2	<b>Strobe</b>		
			0	31	LED off
			32	95	Strobe-effect with increasing speed
			96	127	LED on
			128	159	Pulse-effect with increasing speed
			160	191	LED on
			192	223	Random strobe-effect with increasing speed
224	255	LED on			
		7	<b>Color change / sound control</b>		
			1	100	Switching colors with increasing speed
			101	200	Fading colors with increasing speed
			201	255	Sound control with increasing sensitivity