

## DMX Chart

The laser uses 14 DMX channels, so make sure that the next device uses an address that doesn't overlap with this range.

Channel	Value	Function
1	0 - 49	Laser off
	50 - 99	Sound-to-Light mode
	100 - 149	Stand-alone mode
	150 - 255	DMX mode
2	0 - 255	Pattern selection
3	0 - 127	Rotation angle selection
	128 - 191	Rotation counter-clockwise speed
	192 - 255	Rotation clockwise speed
4	0 - 127	Rotation X position steps
	128 - 255	Rotation X speed
5	0 - 127	Rotation Y position steps
	128 - 255	Rotation Y speed
6	0 - 127	X-axis movement position
	128 - 255	X-axis movement speed
7	0 - 127	Y-axis movement position
	128 - 255	Y-axis movement speed
8	0 - 255	Size X from big to small
9	0 - 255	Size Y from big to small
10	0 - 255	Gradient speed
11	0 - 127	Scan speed
	128 - 255	Point speed
12	0 - 24	Original color
	25 - 199	Color selection
	200 - 224	Automatic color change effect
	225 - 255	Rainbow color change effect
13	0 - 255	Speed adjustment for automatic color change effect and multi color step through
14	0 - 255	cycle through grating effects per 50 value